


## ROV-1500 Standard Spares Kit

**NOTE:**

- Additional spares options can be chosen from the Spares Add-On List.
- Hand controller is not part of spares kit, spares box is used for transport of hand controller only.



Qty Each	Part #	Description
2	01-0108	T200 Thruster Assembly with Connector
1	03-0173	BR Silicone Grease
3	03-0087-LH	T-200 LH Prop
3	03-0087-RH	T-200 RH Prop
2	03-0324	Shaft Anode 3/4in
4	03-0343	Slide-In T-Nut 1/4-20, SS
1	03-0344	Screwdriver with reversible bit
1	03-0381	ROV Thumb Drive
2	11-0491	Thruster Quick Release Plug
2	11-0761	Half Weight Adaptor
8	12-2599	THMS M3 X 8, FT, 18-8SS
10	12-2435	#10 x 1in Truss head Sheetmetal Screw, SS
10	12-2462	#10 x 1/2in Truss Head Sheetmetal Screw
1	25-0074	3M Straight Splice Mold Kit
1	26-0013	Connector In-Line 3 Pin Female Micro Wet-Con
1	26-0022	Connector In-Line 8 Pin Female Micro Wet-Con Cat5
3	26-0041	Locking Sleeve MCDLS-F
1	26-0042	Locking Sleeve MCDLS-M
1	26-0058	Dummy Plug 8 Pin Male Micro Wet-Con
1	26-0060	Dummy Plug 4 Pin Male Micro Wet-Con
1	26-0061	Dummy Plug 3 Pin Male Micro Wet-Con