

## ROV-3000 Standard Spares Kit

**NOTE:**

- Additional spares options can be chosen from the Spares Add-On List.
- Hand controller is not part of spares kit, spares box is used for transport of hand controller only.



Qty Each	Part #	Description
2	01-0279	T500 Thruster Assembly with Splice and Connector
1	03-0018-4	821 UltraCase/Foam
1	03-0173	BR Silicone Grease
3	03-0237-LH	T-500 LH Prop
3	03-0237-RH	T-500 RH Prop
2	03-0324	Shaft Anode 3/4in
1	03-0338	Hex Screwdriver
4	03-0343	Slide-In T-Nut 1/4-20, SS
1	03-0344	Screwdriver with reversible bit
1	03-0381	ROV Thumb Drive
2	11-0491	Thruster Quick Release Plug
2	11-0761	Half Weight Adaptor
1	11-0840-1	Top Pluck foam
1	11-0840-2	Bottom Pluck foam
8	12-2192	THMS M4 X 10, FT, 18-8SS
10	12-2435	#10 x 1in Truss head Sheetmetal Screw, SS
10	12-2462	#10 x 1/2in Truss Head Sheetmetal Screw
1	25-0074	3M Straight Splice Mold Kit
1	25-0092	CAT5 Cable with Male to Female locking sleeves
1	25-0095	ROV Tether to Power Bottle Cable
1	26-0013	Connector In-Line 3 Pin Female Micro Wet-Con
1	26-0022	Connector In-Line 8 Pin Female Micro Wet-Con Cat5
3	26-0041	Locking Sleeve MCDLS-F
1	26-0042	Locking Sleeve MCDLS-M
1	26-0058	Dummy Plug 8 Pin Male Micro Wet-Con
1	26-0060	Dummy Plug 4 Pin Male Micro Wet-Con
1	26-0061	Dummy Plug 3 Pin Male Micro Wet-Con